

**Board For
EG91X-XX**

- SDA
- SCL ● RST
- DP0
- DN0
- CN
- DP1
- DN1

Powered by
QuecPython

● GND
● 3V3

RX2 TX2

C1-P02
XINT

Made in China

MIC SPK

USB

PWR_AUTO VDD_EXT NFCU_EN SD_EN GNSS_EN

Cam_VDD


9062
SCK1

ADC

DIV/WIFI

GNSS

SD 2.0



- DAT3
- DAT2
- DAT1
- DAT0
- CLK
- CMD
- VDD

SIM1

- VDD
- DAT
- CLK
- RST

RST2 VDD2 ● ●